



PA-123 and PA-123B

Overhead Projectors, these newly designed Overhead Projectors are constructed of sturdy steel. Each unit comes with a rapid lamp switchover just in case one of the bulbs burns out (2 lamps are supplied with each model). Model PA-123 has a single achromatic adjusting system and model PA-123-B comes with 3-element achromatic optical system to produce the highest quality in resolution. This sharp image of high-magnification can easily be obtained with a short distance from the screen. Both projectors are very easy to operate and are suitable for use in Schools, labs and for presentations. Each unit comes complete with 2 x 250W tungston halogen lamps, glare-free fresnel lenses, tilting head, rack-and pinion focusing mechanism with large focus knob. Complete with three-wire ground cord and plug. CE approved.

	Model PA-123	Model PA-123B
Objective	1 len F : 280 mm	3 lens F : 320 mm
Lamp	2 x 250W / 24V	2 x 250W / 24V
Working Stage	250 x 250 mm	250 x 250 mm
Low-noise Cooling System	less than 40dB	less than 40dB
Voltage (50 - 60Hz)	110 / 220 / 230 / 240V	110 / 220 / 230 / 240V
Light Output	2800Lm	3200Lm
Fuse	2.5A	2.5A
Elevation Angle of Projection	40 deg = 65 deg	40 deg = 65deg
Projection Distance	105m - 3m	105m - 3m
Packing Dimensions	50 x 46 x 33cm	50 x 46 x 33cm
Net Weight	10 kgs	10.4 kgs
Gross Weight	12.4 kgs.	12.8 kgs